



Important Note

Our bathtubs are Double Wall Construction. The drain needs to be installed with **Silicone**, not Plumbers Putty.

Using plumbers putty will not seal the two bathtub layers properly. Using **Silicone** on the drain threads and drain cavity will completely seal the drain connection to the bathtub.

